

Installation instruction do88 intercooler pipes for SAAB 9-3 2.8T V6



This instruction shows how to replace the OEM intercooler pipe with do88 performance intercooler pipe.

At this type of installation we always recommend that you have mechanical experience and knowledge about safety during work on vehicles.

Parts included:

1. Intercooler pipe Turbo – Intercooler
2. Intercooler pipe Intercooler – Throttle body
3. Turbo outlet silicone hose
4. Intercooler Inlet silicone hose
5. Intercooler Outlet silicone hose
6. Throttle body silicone hose
7. Hose clamps 40-60mm 1pc, 60-80mm 7pcs
8. M5x12mm screw
9. M6x16mm screw


Part number: TR-110



1. Remove battery cover by loosen the two plastic screws in the front end, remove coolant hose from the groove and lift the cover away.

Remove the air guide positioned between radiator support and battery box by lifting it up from battery box and then pull out to the rear.

Remove the negative terminal from the battery post and make sure it will not be in contact with the battery terminal.



2. Remove the 4pcs 8mm hex head screws in each front inner fender.



- 3.** Remove 6pcs plastic rivets in the top of the bumper above the upper grille by pushing the center piece of them downwards a few millimeters (about 1/8") and then pull it up in the collar.

Cars with facelift 08-> have 4 pcs of plastic rivets and 2pcs of Torx T30 screws instead.



- 4.** Remove the 4pcs of 8mm hex head screws marked on picture.

Bend down the outer left "corner" (2.) of the front protecting plate and disconnect the electric connector attached to it and make sure vehicle chassis harness are not attached to the protecting plate.


On vehicles with high pressure cleaning of headlight: Disconnect the hose to the headlight nozzles from the pump positioned in the washer fluid tank above the same "corner" (2.).
NOTE! Washer fluid might pour out.



- 5.** Pull the rear end of bumper out from the car until it comes loose on both sides of vehicle.




6. Remove the headlights by removing 3pcs of 10mm (on facelift 2pcs 10mm & 1pc 7mm) hex screws on each headlight and then pull/lift forward so you can disconnect the electrical connector from the headlight and then remove headlight from vehicle.



This type of electrical connector are disconnected by pulling the red part out from it at the same time as the male and female connectors are pullet apart.



7. Disconnect the electrical connector from the horn and remove the cable clips from the front cross member.




8. Remove the two Torx T25 screws that secures the air inlet pipe to the radiator support.



9. Remove the radiator support by removing 8pcs of 10mm (on facelift 6pcs) hex head screws on top of it and 2pcs of 10mm hex head screws in the bottom of the cross member.


Protect the battery terminals so they will not be shorted and then lift up and position the radiator support with cross member above the engine compartment so it's not on top of the radiators.



10. Loosen the hose clamps at the air filter box and air mass meter.

Disconnect the plastic hose by pressing the plastic ring together and pulling it outwards.


Now remove the pipe from the car.



11. Remove the oil filler cap. Then remove the engine cover by gently pulling it upwards in each corner. Now put back the oil filler cap.

12. Loosen the hose clamps at the throttle body and at the hose between the two pipes.


Now disconnect the sensor cable and then remove the pipe from the car.




13. Remove the two plastic air guides next to the intercooler inlet and outlet connections. 2x 10mm Hex nuts.




14. Loosen the hose clamps at the intercooler outlet and at the pressure pipe. Now remove the hose from the car.



15. Remove the two radiator top brackets on both sides, 4x 10mm screws.



16. Gently tilt the radiator forward and then remove 3x E10 Torx from the pressure pipe. Remove the pressure pipe from the car.




- 17.** Install the throttle body silicone hose with a included 60-80mm hose clamp. Turn the hose so the pressure pipe will be slightly higher than the throttle body.
- Now install the large pressure pipe. Gently “screw” the pipe clockwise into position according to the picture.




- 18.** Insert the do88 performance pipe into the throttle body hose and fasten it with a included 60-80mm hose clamp. Fasten the do88 performance pipe with the included M6x16mm screw.

- 19.** Remove the pressure sensor from the OEM pipe 1xT25 screw. Install the pressure sensor in the do88 performance pipe with the included M5x12 screw.

- 20.** Install the silicone hose between the intercooler outlet and the do88 performance pipe with two included 60-80mm hose clamps.



- 21.** Remove the E10 Torx from the intercooler inlet pressure pipe.
- Then loosen the hose clamps at the intercooler inlet and turbo outlet.
- Now remove the pressure pipe from the car.



- 22.** Install the do88 performance pressure pipe and silicone hoses according to photo.
- 2x Silicone hoses
 - 1x Pressure pipe
 - 1x 40-60mm hose clamp
 - 3x 60-80mm hose clamp

- 23.** Reinstall all other parts in reverse order.

24.

Finished.



do88
Performance

Swedish performance since 2007